

Oven Lock

To install:

1. Locate area where plates will be positioned. Plates must be placed on clean, smooth surface. Clean surfaces with alcohol and dry thoroughly.
2. Insert prongs of side plate into holes of front plate making sure hinge is in position. Align both pieces with front and side of oven. Mark end and bottom of both plates with a pencil.
3. Separate front and side plates. Remove paper from adhesive on back of side plate. Press firmly in place within pencil marks on side of appliance.
4. Remove paper from adhesive on hinge of front plate assembly. Press firmly into position on front of appliance.

To open:

Squeeze prongs of side plate together and open appliance door.

To clean:

Wipe with damp cloth and dry.

CAUTION: This product is only a deterrent. It is not a substitute for proper adult supervision. Discontinue use when child becomes old enough to defeat it.



©2007 Dorel Juvenile Group.
All Rights Reserved.
www.djgusa.com (800) 544-1108
www.safety1st.com
Made in CHINA. Fabriqué en CHINE.
Styles and colors may vary.
Les styles et couleurs peuvent varier.
Distributed by (distribué par)
Dorel Juvenile Group, Inc.,
2525 State St., Columbus, IN 47201-7494
Dorel Distribution Canada,
873 Hodge, St. Laurent, QC H4N 2B1
12/07

Loquet pour le four

Installation:

1. Repérez l'endroit où les plaques seront placées. Les plaques doivent être placées sur une surface propre et lisse. Nettoyez les surfaces avec de l'alcool et séchez à fond.
2. Insérez les pattes de la plaque latérale dans les trous sur le devant de la plaque en vous assurant que la charnière est en position. Alignez les deux parties avec le devant et le côté du four. Marquez l'extrémité et le dessous des deux plaques avec un crayon.
3. Séparez les plaques avant et latérales. Retirez le ruban de l'adhésif au dos de la plaque latérale. Pressez fermement en place à l'intérieur des marques au crayon sur le côté de l'électroménager.
4. Retirez le ruban de l'adhésif sur la charnière de l'assemblage de la plaque avant. Pressez fermement en place sur le devant de l'électroménager.

Pour ouvrir:

Pressez les pattes de la plaque latérale ensemble et ouvrez la porte du four.

Pour nettoyer:

Essuyez avec un chiffon humide et séchez.

ATTENTION: Ce produit est seulement un moyen de dissuasion. Il ne remplace pas la supervision appropriée d'un adulte. Cessez l'utilisation quand l'enfant est capable de le déjouer.